





**WS10b Spare Parts
Spec Sheet**



**Frame Only
136651**



WS10b Spare Parts Spec Sheet



A (16)
45 mm Bolt Kit
138949

B (12)
40 mm Bolt Kit
138953

C (4)
33 mm Bolt Kit
138954

D (4)
Philips Foot Bolt 42 mm
138718

E (24) 138719
Philips Ceiling Bolt 20 mm
F 138720

F (4)
Cap Screw 19 mm
138710

G (8)
Loop Pad Screw 15 mm
138716

H (16) 138722
Bearing (16)
138722

I (32) 138723
Washer (32)
138723

J (8)
Spring Button 138724

K (1) 138729
Center Junction (1)
138729

L (4) 138745
Ceiling Joint (4)
138745

M (4) 138751
Nylon Cap (4)
138751

N (4) 138757
Slider (4)
138757

O (4) 138789
Loop Pad (4)
138789

P (4) 138761
Square Foot (4) 138761

Q (20) 138764
Hex Tube Cap (20)
138764

R (8) 138768
Round Tube Cap (8)
138768

S (8) 138772
Hex Tube Sleeve (8)
138772

T (8) 138776
Round Tube Sleeve (8)
138776

U (4) 138780
Tube Plug (4)
138780

V (4) 138784
Square Leg Sleeve (4)
138784




WS10b Spare Parts Spec Sheet


Accessories
Stakes 132459









Canopy Cover (1)
Blue 138978



Wheeled Bag (1)
138916



- Y** Square Inner Leg 21 x 21 | x 1029 mm 138796
 (4)
- Z** Square Outer Leg 25 x 25 x 1220 mm 138814
 (4)
- A** Oval Eaves 12 x 23 | x 1156 mm 138867
 (16)
- B** Fiberglass Higher Ceiling 778 mm 138884
 (4)
- C** Fiberglass Ceiling Support 660 mm 138887
 (4)
- D** Fiberglass Lower Ceiling 837 mm 138889
 (4)